

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



ACE6062501
111305515220
Roller Cap



ACE6062506
11158201600
Excenter Roller Dia-50



ACE6062510
11164005800 / 11401391010
Swinging Lever Assembly



ACE6062510B
12491300602
Plain Bush Dia6x12x12



ACE6062511
11158073000
Pivot Pin



ACE6062513
11158072900
Pivot Cap - 36



ACE6062515
11130216230 / 11158330930
Jockey Lever



ACE6062517
11130824310
Nilos Ring

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



ACE6073707
11130551810
Heddle Belt - EX



ACE6074720
11158027510
Lower Heddle Belt - 16BP



ACE6074722
11130603800
Heild Wire



ACE6076020
11158244310
Lower Heddle Belt -A(16w)



ACE6076501
11131011300/11131011310
Tension Bolt



ACE6076505
11131715500
Upper Bearing Block




ACE6076507
11158026700
Upper Heddle Belt



ACE6076509
11131509920
Deflecting Pulley

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



ACE6076513
11130508010
Connecting Plate



ACE6076514
11131550720
Connecting Strip



ACE6076517
11130610310
Woolen Felt Cap



ACE6076524
11131511010
Deflecting Pulley



ACE6081301
11158201500
Pusher Wheel-T



ACE6081305
11130850700
Cover - Pusher Roller



ACE6081408
11158055310
Stopper Wheel



ACE6091001
11158180800
Insertion Finger-I (p) 685-920 DFL

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



ACE6091002
11158180900
Insertion Finger-m(P) 480-685 dfl



ACE6091003
11158181000
Insertion Finger-s (p) 300-480 DFL



ACE6091004
11130557900
Lever Holder



ACE6091007
11130558000/11404895000
Weft Compensation Lever (magnet)



ACE6111407A
11401308000 /11130006510
Compensator With Eye



ACE6111407C
12470200002
Mailons 160C



ACE6111408
11131652420
Compensator Spring



ACE6111409
11131603310
Spring Holder

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



ACE6111423
11158027100
Positioning Separator



ACE6362109
11131322710
Shaft



ACE6362115
11131322800
Shaft Pinion 10T



ACE6362205
11131201700
Driven Disc



ACE6362207
11131489300
Shaft Gear



ACE6362304
11131474600
Driving Disc with 10 Magnets



ACE6362316
11131225900
Magnet 32x16x8



ACE6596006
11130601200
Spring for Low Denier-1

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



ACE6599604
11130521500
Clamp



ACE6599605
11130521900
Clamp - Shuttle Guide



ACE6599607
11158200700/11158201100
Shuttle Roller -P



ACE6599612
11130215420/11130215430
Bearing Block -P (front)



ACE6599613
11130521600
Clamp (left)



ACE6599614
11130521700
Clamp (right)



ACE6599615
11158246000/11407562000
Shuttle Body -Wg (machining)



ACE6599619
11158161600/11158161610
Shuttle Guide -P

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



ACE6596007
11130601700/11407032010
Spring for Low Denier - 2



ACE6596008
11130601400/11407030010
Spring for Medium Denier



ACE6596009
11130601500/11407033010
Spring for Heavy Denier



ACE696015
11158018000/11158018010
Insertion Pipe -P1



ACE6596016
11158018100/11158018110
Insertion Pipe -P2



ACE6596018
11158018300/11158018310
Insertion Pipe -P4



ACE6599601
11158161900/11158389710
Wrap Guide -P



ACE6599602
11130521800
Bearing Block (rear)

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



ACE6645025
11131467400
Polyurethane Foam Roller



ACE69945501
11130522000
Chonchoid Cap -P



ACE6994503
11158201310/11158201320
Chonchoid Wheel -P-M-42



ACE6994511
11158200900 / 11158200910
Stopper Wheel -P



ACE6994514
11158201000/11404774000
Shuttle Wheel -P



ACE6994515
11130442120
Eccentric Adapter



ACE6994601
11130602700
Leather pad with Tesafix



ACE6994603
11130521200
Tension Pad -P

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



ACE6994604
11130510800
Bush for Spring



ACE6994607
11131537500
Brake Bearing



ACE6994608
11130607000
Weft Tension Spring



ACE6994611
11130828210/11407153000
Spring Strecher -P




ACE6994613
11131512210
Bush for Spring



ACE6994701
11130441900
Cover Front -P



ACE6994702
11130441810
Bobbin Holder-P (fixed end)



ACE6994704
11130442000
Cover Back-P

WEAR & TEAR PARTS FOR CIRCULAR LOOM


ACE 6




ACE6994707
11158248400
Compression Spring Dia1.6




ACE6994709
11130441600
Bobbin Holder-P (floating end)



ACE6994712
11164018500/11401741000
Sider Washer Assy



ACE6660715
11147250166
Wrap Sensor Card



ACE6165805
11147250177
Weft End & Latch Card for Loom



ACE6660729
14024101640
OL Relay W1NO 1NC 1-1.6A



ACE6602109
14401021002
Ind. Proxy Flush PNP No M8W
sh Cable 3KHz



ACE6707005
14402021000/11981028000
Ind. Cyl Proxy W con PNP No M8 Flush

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



ACE6123506
14460001001/11981003000
Photoswitch, PNP, Prog o/P, M18



ACE6169259
15410110000
SMPS 230VAC/ 24VDC72W Din Rail



12470310038/12470310241
Rubberised Emery Cloth(grey) 100mm
Wide



ACE6599600
11401051000
Plastic Shuttle Assembly



11401067000
Cam roller Assy



11158952700/11401352000
Chonchoid Wheel-P (asmbd)



11158952800/11401353000
Stopper Wheel -P (asmbd)



11145001930/11401349000
Shuttle Roller Assy

WEAR & TEAR PARTS FOR CIRCULAR LOOM

ACE 6



11145001020/11401354000
Shuttle Wheel Complete



1158953000 / 11158953000
Weft Guide ceramic With Finger Holder